




Edgetec ABS Extension Adapter



Series

Order No.	Model	Size (mm)		Thrust screw	Receiving screw	Floating pin	Orientation pin
		dm	L				
141-11-001	ABS25/25-45	25	45	21A.25-E1	21A.25-E2	21A.25-E3	21A.25-E4
141-11-002	ABS25/25-60	25	60	21A.25-E1	21A.25-E2	21A.25-E3	21A.25-E4
141-11-003	ABS32/32-50	32	50	21A.32-E1	21A.32-E2	21A.32-E3	21A.32-E4
141-11-004	ABS32/32-70	32	70	21A.32-E1	21A.32-E2	21A.32-E3	21A.32-E4
141-11-005	ABS40/40-60	40	60	21A.40-E1	21A.40-E2	21A.40-E3	21A.40-E4
141-11-006	ABS40/40-90	40	90	21A.40-E1	21A.40-E2	21A.40-E3	21A.40-E4
141-11-007	ABS50/50-65	50	65	21A.50-E1	21A.50-E2	21A.50-E3	21A.50-E4
141-11-008	ABS50/50-100	50	100	21A.50-E1	21A.50-E2	21A.50-E3	21A.50-E4
141-11-009	ABS63/63-85	63	85	21A.63-E1	21A.63-E2	21A.63-E3	21A.63-E4
141-11-010	ABS63/63-125	63	125	21A.63-E1	21A.63-E2	21A.63-E3	21A.63-E4
141-11-011	ABS80/80-85	80	85	21A.80-E1	21A.80-E2	21A.80-E3	21A.80-E4
141-11-012	ABS80/80-125	80	125	21A.80-E1	21A.80-E2	21A.80-E3	21A.80-E4
141-11-013	ABS100/100-85	100	85	21A.100-E1	21A.80-E2	21A.100-E3	21A.100-E4
141-11-014	ABS100/100-125	100	125	21A.100-E1	21A.80-E2	21A.100-E3	21A.100-E4
141-11-015	ABS100/100-160	100	160	21A.100-E1	21A.80-E2	21A.100-E3	21A.100-E4