


## **BACK PLUNGER DIAL INDICATOR**









· Used to measure surface flatness as well as axial runout and also used to check tool set up and squareness in small spaces where the standard dial indicators are difficult to see



Limit indicator clips included

Unit:mm

Code	Range	Graduation
5271-0005	0-5	0.01

